


WAC OPERATION SYSTEM PARTS LIST



**WAC- 3800 OS:
Jacquard computer (w/o encoder)**



WAC- 3800 OS: Encoder



WAC 3800 OS: 8 steps actuator(w/o IC)



WAC 3800: 8 steps actuator driver board



WAC 3800 OS: 16 steps actuator(w/o IC)



WAC 3800 OS : 16 steps actuator driver board

WAC OPERATION SYSTEM PARTS LIST




**WAC 3800 OS : Jacquard
computer LCD screen**



**WAC 3800 OS : Jacquard
computer LCD screen**




Actuator Connecting Cable(24-port)



Operation Touch Screen



**WAC- 3700/3800 OS:
Jacquard computer Soft driver**



**Piezoelectric ceramics
(2wire/ 3wire -available)**

WAC OPERATION SYSTEM PARTS LIST



**WAC- 3800 OS:
Jacquard computer main A-board**



**WAC- 3800 OS:
Jacquard computer A drive board**



**WAC- 3800 OS:
Jacquard Computer main B-board**



WAC- 3800 OS: 3position B Drive Board



**WAC 3800 OS:
Floppy drive W/usb**



WAC- 3800 OS : PC power supply